

QR-AB1 & QR-AB1QR



- a 1/8" Allen Wrench
- b 1/4"-20 Cone Points
- c 5/32" Allen Wrench
- d 1/4"-20 Button Head Bolts



The Universal QR assembly fits several styles of other manufacturers quick release plates that are not Arca-Swiss compatible.



1. Remove the QR clamp from mounting block with supplied 5/32" Allen wrench.



2. Remove the OEM bolts from the manufacture's plate if they can be removed and insert the button head bolts supplied with the Universal QR clamp assembly. Turn the QR block upside down.



3. Place manufacture's plate with bolts inserted and line up two parallel thread holes in the QR block and tighten with the supplied 5/32" Allen wrench.



4. Turn the plates over so the QR Block is on the top.



5. Attach the QR clamp to the block and tighten with supplied 5/32" Allen wrench.



6. QR clamp can be positioned any 90° depending on your preference and if you are using a camera plate or lens plate.



7. If your manufacture's QR Plate has a captive screw that cannot be removed, attach the plate to the bottom of the QR Block.



8. Make sure that the QR Block and the manufacture's plate line up parallel to each other.



9. Insert at least two cone point screws into the QR Block making sure they do not line up with a hole or gap in the manufacture's plate and tighten with 1/8" Allen wrench.



10. Attach the Quick Release clamp on the QR block as in 5 above.