

MOUNTING DIRECTIONS FOR YOUR NEW KIRK REPLACEMENT COLLAR

#1 REMOVE ORIGINAL TRIPOD COLLAR FROM LENS. FOR DIRECTIONS ON HOW TO DO THIS PLEASE REFER TO YOUR ORIGINAL LENS MANUAL

#2 REMOVE SILVER KNOB ON THE REPLACEMENT COLLAR.

#3 OPEN YOUR NEW KIRK COLLAR ALL THE WAY UP. MAKE SURE THE SPRING IS IN THE SPRING HOLE (THE HOLE WITHOUT THREADS). LINE PINS UP ON THE LENS TO THE GROOVE ON NEW COLLAR. PUT THE SIDE OF THE NEW COLLAR WITH THE BASE ON FIRST -HOLD THIS AGAINST THE LENS THEN CLOSE THE HINGE SIDE DOWN ONTO IT. THIS IS THE EASIEST WAY TO GET THE BEST FIT

ON NC-70-200, NC-300PF, OR SRC-70-200-4 PUT THE NEW COLLAR ON THE LENS AND CLOSE COLLAR TOGETHER-THESE DO NOT HAVE PINS TO LINE UP. PUT THE SIDE OF THE NEW COLLAR WITH THE BASE ON FIRST -HOLD THIS AGAINST THE LENS THEN CLOSE THE HINGE SIDE DOWN ONTO IT.

#4 INSTALL SILVER KNOB INTO NEW COLLAR.

TO ROTATE REPLACEMENT COLLAR ON THE LENS: ONLY LOOSEN THE KNOB 1/4 TURN

TIPS

FOR MORE PRECISE ROTATION FROM VERTICAL TO HORIZONTAL, USE THE MAIN LOCK KNOB TO CONTROL THE AMOUNT OF DRAG ON LENS. ONLY LOOSEN THE KNOB 1/4 TURN TO ROTATE

DO NOT OVER TIGHTEN THE MAIN LOCK KNOB. YOU DO NOT HAVE TO TIGHTEN AS TIGHT AS ORIGINAL TRIPOD COLLAR TO LOCK LENS FROM ROTATING.

IF YOU HAVE ANY QUESTIONS PLEASE CALL 260-665-3670 OR EMAIL US AT INFO@KIRKENTERPRISESOLUTIONS.