



1. Position the L-bracket to the bottom of your camera as shown in the photo. Determine which slot will work best with the threaded screw socket in the bottom of your camera.



2. After locating the position that works best for your needs, simply insert the 1/4-20 camera screw (screw is in bag with orange label) into the camera body tripod socket with the hex wrench that is located on the bottom of the L-bracket and fully tighten the screw into position.



3. Re-insert the 5/32 hex wrench into the wrench holder. Now your L-bracket is ready to use.

**Please Note:**

**\*Occasionally retighten the camera screw to help prevent twisting of the camera body.**